

Jacking Pads for C7 and Grand Sport Corvettes w/Side Skirts



The C7 Stingray pictured on the left was not correctly placed on a lift!

According to the C7 Corvette Owner's Manual, Pages 10-4 & 10-5 you can use the frame rails to lift the car but:

"Be sure to place a block or pad between the jack and the vehicle. Use only a jack with a lift pad of 64 mm (2 ½ inches) or smaller and thick enough to make sure the jack does not contact the vehicle body."

"CAUTION: The jack pads must not contact the rocker panels, fenders or floor pan. If they do damage will occur."

Use Shipping Slots

The manual does show and sketch (below) and states: "Position the jack and lifting pad under the frame rail shipping slot reinforcement."

What they are referring to as lifting pads

are the devices often referred to as "Jacking Pads" since many folks have made these from hockey pucks using large threaded eye hooks to hold them into the slots. But hockey pucks are 3 inches in diameter and a view of the C7 slots show they are closer to the rocker panel than the C6.

The 3 inch aluminum jack pads I used for my C6 would be too large in diameter.

The solution, buy (or make) pads that fit correctly. The following pictures show several jack pads 2 ½ inch OD that work. The Appendix shows how a 3 inch Hockey Puck can be assembled to work for a C7 as well.




Photo Sequence: Making Jacking Pads for a C7 Corvette

The photo on the left side of this picture was from a review by Edmonds. The rear slot looked more round than oval. The two pictures to the right were taken by me at Laguna Seca. They also show the rear slot appeared more oval. Perhaps it was the angle the picture was taken. (See Appendix for possible reason the pictures I took were not representative of production cars.)

Our C7 Crystal Red, Z51 arrived and checking at first confirmed the visual difference in shape. However made clay impressions and they were about the same size, just at different angles to the frame.



In the past hockey pucks have been used but they are 3 inches in diameter. A Forum Member sent me a PM and said they do work for his car. **See Appendix** as one way they can be assembled to clear the rocker panels,



KaTech offered an excellent jacking puck. They are 2 ½ inch diameter so meet the Chevy recommended maximum diameter. They offer them in 1 inch and 2 inch height for Vette's with side skirts, including the ZR1 C6 etc. Bought 4 to bring to the dealer in case they wish to use their post lifts. This avoids their large lift pads hitting the side skirts!

KaTech also has a one-inch high aluminum puck! I use one in a "long arm reach jack" that I welded on a ½ inch high extension to the saddle. That allows the jack pad fitting tightly in the shipping slot to "pull" the jack into the car as it is raised!

It is critical that the jack saddle remains under the Jack Pad and as it raises. If the jack does not move into the car the saddle will slide off the jack pad as the saddle moves to the outside!





For my new Grand Sport did not need the high 2 inch KaTech pads as the OEM Stage 2 carbon fiber side skirts clear all my jacks with a 1 inch high pad. At a dealer or tire store using a center post lift an inch pad is sufficient to provide the needed clearance.

Always had a concern when leaving Jack Pads on the passenger seat in a clear plastic bag for the dealer/tire shop to use. Would they!

Reverse Logic offered a new pad that had a clever way to use as I would normally when working on the car at home, just insert, twist, and remove when the task was complete. But they also had an alternate possibility.



The Reverse Logic pads can be disassembled using an Allen wrench and the white spacer removed. Then they can be inserted in the shipping slot and the bolt tightened so they are semi-permanently mounted. Then carefully drive to the dealer/tire dealer and be assured they will be used!

When back home they are removed so they are not sticking down and possibly hitting something or coming loose.


Reverse logic also offers a 15 m (~5/8 inch) spacer that comes with a longer bolt. It can be added to increase the jack pad height.



APPENDIX:

Received a message from a forum member who said their home made hockey puck pads they had used on their C6 worked fine on their C7. There was clearance from the plastic rocker panel.

There is no doubt some variations exist in how close the rocker panels comes to the shipping slots. The picture right was taken of what GM called an IVER, a preproduction C7 I saw at the Vintage Car Races in August 2013 at Laguna Seca. Note the small clearance to the panel.



Hockey Puck



2"



2 1/2"



3"



Depending on how the Hockey Puck pad is made, the relatively small diameter of the eye bolt screw allows the hockey puck to be inserted to one side of the shipping slot. Therefore a 3 inch diameter pad puck can have the same clearance as a 2 1/2 inch pad that uses a larger diameter support close in diameter to the slot itself!

Bottom Line: Look carefully at the clearance of the pad you use and be sure it doesn't touch the rocker panel.

Other 2017 Grand Sport & 2014 Stingray PDF's Available:



Some 40 items discuss improvements or information about a 2017 Grand Sport and 2014 Stingray function and/or esthetics. Some are minor and others, like the installing ceramic brake pads, include detailed install information.

Below are the PDF's available. Click on picture (may need Ctrl pressed.) Or just copy and paste the PDF info (Blue type) into your browser. Or email me at GUtrachi@aol.com and state the title desired, shown in Yellow:

Note: GS indicates the info was updated from that available for the C7 Z51 PDFs.

Rusty GS/C7 Muffler

*Why the C7 muffler is rusted and a simply way to make rust turn matte black.
Bottom pic rusted, top pic treated*

http://netwelding.com/Muffler_Rust.pdf



Change GS/C7 Oil

*WHY change your own oil and HOW to do it
Revised, includes C7 Lifting Methods*

http://netwelding.com/Changing_Oil.pdf



C7 Carbon Fiber Side Skirts

*How to install side skirts with jacking information for
DIY's without lifts*

http://netwelding.com/Side_Skirts.pdf



C7 Carbon Fiber Splitter w/End Plates

How to install Splitter & Nylon bra fit

http://netwelding.com/CF_Splitter.pdf



C7 Removing GM Plastic Film

How To Remove The Rocker Panel Film

http://netwelding.com/Rocker_Panel_Film.pdf



GS/C7 Mirror Proximity Alarm

Limit switch alarm warns when passenger mirror is too close to door frame

http://netwelding.com/Mirror_Proximity_Alarm.pdf



Jacking Pads for GS/C7

Jacking Pads must 2 1/2 inch max OD. Made four. Bought 2 1/2 inch OD x 2 inch high pads after installing side skirts; Bought pads right for the GS.

http://netwelding.com/Jacking_pads.pdf



GS/C7 Radar Power

For C7 tapped rear fuse panel. For GS tapped mirror

http://netwelding.com/Radar_Detector_Power.pdf



GS/C7 Belt Rattle

Passenger seat belt rattles against the seat back. The solution, add a shoulder belt pad.

http://netwelding.com/Eliminate_Rattle.pdf



Aluminum C7 Chassis and Weld Repair

The C7 has an all aluminum chassis, made from 117 welded pieces

http://netwelding.com/Aluminum_Chassis.pdf



GS/C7 Ceramic Brake Pads

The Z51 has very dusty brakes. These pads help!

http://netwelding.com/Ceramic_Pads.pdf



GS/C7 License Plate Frame;

Must Meet South Carolina Law

http://netwelding.com/License_Plate_Frame.pdf



Manage GS/C7 Spilled Gas

Protect the side of the Vette when filling up with gas

http://netwelding.com/Manage_Spilled_Gas.pdf



GS/C7 License Plate & Cargo Lights

LED license plate light & cargo area bulbs are brighter and whiter

http://netwelding.com/License_Plate_Light.pdf



GS/C7 Rear Cargo Area

Rear cargo area needs storage device and rear protector

http://netwelding.com/Rear_Cargo_Area.pdf



GS/C7 Door Panel Protector

Black plastic protector added to prevent scuffing of door when exiting

http://netwelding.com/Door_Panel_Protector.pdf



GS/C7 Improved Cup Holder

A solution to the cup holder spilling under hard braking or sharp turns.

http://netwelding.com/Improved_cup_Holder.pdf



GS/C7 Wheel Chatter/Hop

Why sharp, low speed turns with cold tires causes the front tires to chatter/hop.

http://netwelding.com/Wheel_Chatter.pdf



C7 Carbon Fiber Grille Bar

Install genuine carbon fiber grille bar overlay

http://netwelding.com/CF_Grille_Bar.pdf



Jacking a GS/C7 Vette

Safely jacking either front only or back & front

http://netwelding.com/Jacking_A_C7.pdf



Deer Whistle Installed on GS/C7

Do they work? Plus Install Info

http://netwelding.com/Deer_Whistle.pdf



Replacing C7 Battery

After using a GM type charger and showing fully charged a voltage low, replaced battery with AGM!

http://netwelding.com/Battery_Issues.pdf



GS/C7 Window Valet

Lower Windows with FOB

Window Valet Helps 2014/2015 Latch Hatch

http://netwelding.com/Hatch_Latch.pdf



GS/C7 Splash Guards

GM offers splash guards for the C7 Corvette. An easy DIY installation. ACS Best Front Guards for GS.

http://netwelding.com/Splash_Guard.pdf



GS/C7 Blind Spot Mirror

Smaller rear and side windows cause C7 blind spots. Small "blind spot mirrors" help

http://netwelding.com/Blind_Spot.pdf



GS/C7 Skid Pad Protector

After the air dam, the aluminum "skid pad" hits driveway ramps etc. Plastic protector helps.

http://netwelding.com/Skid_Pad_Protector.pdf



GS/C7 Wheel Locks

Wheel locks, torqued to required 100 ft-lbs, help protect your expensive wheels from theft.


http://netwelding.com/Wheel_Locks.pdf



GS/C7 OnStar Lights

The OnStar LED's in the rear view mirror, at a quick glance, look like a police car flashing light! This is a fix.

http://netwelding.com/OnStar_Lights.pdf



GS/C7 Skip Shift Eliminator

Skip Shift Eliminator install with suggestions on jacking a C7.

http://netwelding.com/Skip_shift_Eliminator.pdf



C7 Catch Can & Clean Oil Separator

Direct inject engines like the LT1, are particularly subject to "coking." What is Coking and how to reduce the potential?

http://netwelding.com/Catch_Can.pdf



GS/C7 Round Shift Knob

A round shift knob shortens throw.

http://netwelding.com/Shift_Knob.pdf



GS/C7 Stingray Sill Plate

Stingray sill plate replaces original.

http://netwelding.com/Sill_Plate.pdf



GS/C7 Nylon Bra

Nylon Bra Stops Bugs on Front and Grill. Fits with Stage 3 Winglets

http://netwelding.com/Nylon_Bra.pdf



GS/C7 Clutch Fluid Change

Clutch fluid after 3000 miles gets dirty

http://netwelding.com/Clutch_Fluid.pdf



C7 Carbon Fiber Hood Vent

Replaces Plastic Hood Vent

http://netwelding.com/Hood_Vent.pdf



GS/C7 Cold Air Intake

Low Restriction Air Filter & Duct

http://netwelding.com/Cold_Air_Intake.pdf



Garmin GPS for GS Cubby

Garmin Mounts in GS Cubby

http://netwelding.com/GPS_In_Cubby.pdf



GS Splitter Stage 3 Winglet

Stage 3 Winglets Integrate with Spats

http://netwelding.com/Stage_3_Winglets.pdf



GS 2LT to 2.5 LT

Red Upper Dash Pad Like 3LT

http://netwelding.com/Red_Dash_Pad.pdf



Jake Emblem/Decals for GS

Jake Symbols Support GS Racing Image

http://netwelding.com/Jake_Emblems.pdf



GS Splitter Protector

Rugged Plastic Protection for Splitter

http://netwelding.com/Splitter_Protectors.pdf



GS Engine Compartment Mods

Cosmetic Additions in Engine Compartment

http://netwelding.com/Engine_Compartment.pdf



GS Vitesse Throttle Controller: Fits All C7s

Adjustable Throttle-by-Wire Control


http://netwelding.com/Throttle_Control.pdf



GS Air Dam, Functions

Why Missing from Z51, Some GS & Z06

http://netwelding.com/Air_Dam.pdf



May Be Of Interest:

Engineering a ProStreet Rod

*How Our '34 ProStreet Rod Was Designed and Built
8.2 Liter Engine, 4 Wheel Disk Brakes & Coilovers*

<http://netwelding.com/Engineering%20Street%20Rod%203-08.pdf>

