

## Nylon Bra for C6, 2014 C7 and 2017 Grand Sport w/Stage 3 Winglets

Car Bras provide protection from debris and the bugs we have in the South! When using the Vette around home, when I return, Bug and Tar Spray is used to remove the splats! However, for a longer trip, at certain times of the year, cleaning the bugs can be a real messy job and they also get in the grill, condenser and radiator.

Having heard issues about abrasion and difficulty with conventional Vinyl Bras, installed a Nylon Bra on my C6 and it worked great. Decided to install one on the C7 and find a way to install the same bra on my Stage Grand Sport with a G Stage 2 aero package that I had installed 5-inch wider Stage 3 winglets.


The following are pictures of the C7 installation of a NoviStretch Bra:

This is a picture of the Nylon Bra Installed on the C6. Worked great and never saw any problems related to abrasion. However, I only used it on long trips and if it was dusty during the trip, in addition to cleaning the car carefully before installing the Bra, cleaned it when I arrived at my destination before returning home. It comes off and on easily



Bought this NoviStretch Bra from RPI Designs. Ordered on a weekend and it arrived on Wednesday! Great service. It is a high-quality product and comes complete with one page of instructions (pic right) and the required screw snaps. However, the pictures shown in the instructions are hard to see. In addition, I made some modifications that will be pointed out here with pics.

You may or may not want to add these extras.



Removing the OEM screws requires a T-15 Torx wrench. I have both a quality T-15 screw driver and a quality T-15 socket that fits a 1/4 inch drive.

Buy a quality tool as I finally had to do to complete a task!

We'll start with the bigger challenge, installing on a Grand Sport with Stage 2 splitter and Stage 3 Winglets



The OEM Stage 2 aero package includes carbon fiber full length side skirts and splitter. Mine are painted carbon flash. To better blend with the Grand Sports spats installed Stage 3 winglets. They are 2 1/2 inch wider per side so 5 inches overall, particularly at the bottom.

Overall fit is fine!



The challenge was to get the NoviStretch Bra to stretch at the bottom snaps.

Removed the three screws from the front inner fender liner. Instead of normal screws for the Stage 3 winglets, I purchased 1 inch long #10 stainless male snaps from Harvard Marine (bottom of pic) and used two different size washers.



These are the three snaps used to hold the Stage 3 winglets. They are recessed but there is room for the male snap on the bra.

For the lower snaps, the bra must stretch about 4 to 5 inches more, making it very tight. Bought 1 ½ inch snap extensions. They are also sold by Harvard Marine for boat covers that shirk over time!

Found it was easier to put the snap extension on the car then snapped the lower bra female snap onto it.



Once the sides are snapped the top right side loop was attached to a protrusion on the right side. No need to remove the plastic section as defined in the instructions.

The left (driver's) side had no such protrusion to slip the bra loop over. Would have to remove the plastic cover, but a quick try showed it was not as easy as on the C6.

Will consider bolting a 2" X 2" piece of black plastic to the right side plastic part to make it easy to connect that loop.



Drilled a pilot hole into the "Splitter Protector" I recently added. See last page for a link to that product and install.

This is the male snap screwed into the protector. In the 2014 C7 was just screwing into plastic so was concerned about the holding power of a snap screw. With the plastic protector was not an issue as it is about 3/16 inches thick. After snapping the left side bra snap, marked drilled and put in the right-side screw.



## Install on C7 Stingray:

Did not have to jack-up the car. As recommended in Step 2 of the printed instructions, turned the wheel to gain access. As mentioned in Step 3 removed and replaced each screw with a snap only one at a time to keep the inner fender aligned. **Don't remove all 3 at once!** Had sufficient room to use the Torx screw driver but the ratchet and socket gave more leverage to press in, if needed- it wasn't.



The OEM screw includes a captive washer. The supplied snaps do not. Since the fender liner is only plastic decided to remove the OEM washers and put them on the supplied snap.

May not be necessary but thought that would be desirable.

### CAUTION:

All screws are going into plastic or Sheet Molding Compound so do not over tighten or you'll strip the plastic!



To remove the captive washer I used a 7/16 inch socket and a vice (see pic). Be careful as quite a bit of force is needed and the alignment must be good or the assembly will slip. Cover with a rag as you tighten the vise so if it slips it doesn't hit you!



The washer will deform slightly but one blow from a hammer on the vise anvil quickly flattened it. It slipped over the supplied snap without having to ream out the hole.



With all screw snaps in place, snap the Bra in place on one side then the other. It will require pulling but that is how it should fit (see pic.)

Once installed, pull down the bottom and tuck it under the bumper. There are two snaps that need to replace two of the bumper screws. It is obvious which screws but they are the third from each end. These are longer screws and removing the captive washers is not easy!

Decided to use small stainless fender washers rather than removing the captive washer. Since they can't be seen, that was a good solution. The instructions do not indicate washers are needed.



Step 7 may appear confusing until you read the text and then look at this picture. The outside bottom corners will not stay on the edge of the bumper. As noted in the instructions, this next step is optional but recommended. The instructions indicate the bolt that holds the outer edge of the air dam just be loosened to provide a gap for the Bra to fit into. I found it required several turns to provide the needed gap. I was concerned the screw could work loose, especially when not using the Bra..



My solution was to use 3 Stainless fender washers per side as a spacer so the screw could be tightened after they were installed.

Your choice, you may elect to skip this step entirely.



If you decide to use this option then you'll need a 7 mm socket. You are simply unscrewing the bolt that holds the corner of the air dam and if you use my approach, place the spacer (it measured 5/32 thick) and put the screw back and tighten.

As will all screws **“Do Not Over Tighten.”**



This a picture of the stacked Stainless fender washers that create the gap. It is a long bolt with sufficient thread to hold tight. This space was sufficient to have the Bra fit in the gap.



This is a picture with the Bra corner inserted into the gap between the bumper and the air dam. Looks like it will hold fine. Will must see how well it holds at high speed.



Steps 8 & 9 are the most difficult to follow until you see these pictures. With the hood open the instructions state to remove the "Plastic Cover" that is held in place with friction clips. This pic is a paper towel roll placed under one edge of the "Plastic Cover" to make it visible.



The “Plastic Cover” referred to actually removes easily, no tools needed. You can see it here resting on the fender.



This is the driver’s side with the “Plastic Cover” removed and the referenced “Frame” (noted in the instructions) exposed. That “Frame” is where you’ll attach the loops that are on the ends of the Bra.



This is a Bra loop placed over the passenger side “Frame.”





Although not mentioned in the Instructions, I was able to place the “Plastic Cover” back over the Bra loop. It does fit in with friction as noted in the instructions. Note on the passenger side there is a cable that fits over it and helps it stay in place. Since I will only be using the Bra for long trips I might leave them off until I remove the Bra



Here is a Pic with everything in place, it fits perfectly.



	Supplied Snap	Purchased	Modified
A	na	0.303	0.260
B	0.161	0.163	0.163
C	0.60	0.99	0.97
D	0.11	0.01	0.05

After installing a carbon fiber Splitter, we found the Nylon Bra stretched over the splitter as well! It did not fit in the gap between the Air Dam and body so it was left loose. However, we found we needed a 1 inch long screw for the snap. We made one but they can be purchased. Try Amazon.

This is a pic on the Bra installed over the Splitter. It fits very well and snaps just as easily as before the Splitter was installed. For details on how it fit and when we located the snaps see the PDF of the Splitter install by scrolling through the following info on all the mods or info provided about the C7.



Other 2017 Grand Sport & 2014 Stingray PDF's Available:



*Some 40 items discuss improvements or information about a 2017 Grand Sport and 2014 Stingray function and/or esthetics. Some are minor and others, like the installing ceramic brake pads, include detailed install information.*

*Below are the PDF's available. Click on picture (may need Ctrl pressed.) Or just copy and paste the PDF info (Blue type) into your browser. Or email me at [GUtrachi@aol.com](mailto:GUtrachi@aol.com) and state the title desired, shown in Yellow:*

**Note:** GS indicates that info may only be in the process of being added to C7 PDFs.

### **Rusty GS/C7 Muffler**

*Why the C7 muffler is rusted and a simply way to make rust turn matte black.*

*Bottom pic rusted, top pic treated*

[http://netwelding.com/Muffler\\_Rust.pdf](http://netwelding.com/Muffler_Rust.pdf)



### **Change GS/C7 Oil**

*WHY change your own oil and HOW to do it*

*Revised, includes C7 Lifting Methods*

[http://netwelding.com/Changing\\_Oil.pdf](http://netwelding.com/Changing_Oil.pdf)



### **C7 Carbon Fiber Side Skirts**

*How to install side skirts with jacking information for DIY's without lifts*

[http://netwelding.com/Side\\_Skirts.pdf](http://netwelding.com/Side_Skirts.pdf)



### **C7 Carbon Fiber Splitter w/End Plates**

*How to install Splitter & Nylon bra fit*

[http://netwelding.com/CF\\_Splitter.pdf](http://netwelding.com/CF_Splitter.pdf)



### **C7 Removing GM Plastic Film**

*How To Remove The Rocker Panel Film*

[http://netwelding.com/Rocker\\_Panel\\_Film.pdf](http://netwelding.com/Rocker_Panel_Film.pdf)



### **GS/C7 Mirror Proximity Alarm**

*Limit switch alarm warns when passenger mirror is too close to door frame*

[http://netwelding.com/Mirror\\_Proximity\\_Alarm.pdf](http://netwelding.com/Mirror_Proximity_Alarm.pdf)



### **Jacking Pads for GS/C7**

*Jacking Pads must 2 1/2 inch max OD. Made four. Also Hockey Puck pad and 2 1/2 inch OD x 2 inch high pads bought after installing side skirts.*

[http://netwelding.com/Jacking\\_pads.pdf](http://netwelding.com/Jacking_pads.pdf)



### **GS/C7 Radar Power**

*The C7 cannot tap the mirror or sun visor for power !*

[http://netwelding.com/Radar\\_Detector\\_Power.pdf](http://netwelding.com/Radar_Detector_Power.pdf)



### **GS/C7 Belt Rattle**

*Passenger seat belt rattles against the seat back. The solution, add a shoulder belt pad.*

[http://netwelding.com/Eliminate\\_Rattle.pdf](http://netwelding.com/Eliminate_Rattle.pdf)



### **Aluminum C7 Chassis and Weld Repair**

*The C7 has an all aluminum chassis, made from 117 welded pieces*

[http://netwelding.com/Aluminum\\_Chassis.pdf](http://netwelding.com/Aluminum_Chassis.pdf)



### **GS/C7 Ceramic Brake Pads**

*The Z51 has very dusty brakes. These pads help!*

[http://netwelding.com/Ceramic\\_Pads.pdf](http://netwelding.com/Ceramic_Pads.pdf)



### **GS/C7 License Plate Frame;**

*Must Meet South Carolina Law*

[http://netwelding.com/License Plate\\_Frame.pdf](http://netwelding.com/License_Plate_Frame.pdf)



### **Manage GS/C7 Spilled Gas**

*Protect the side of the C7 when filling up with gas*

[http://netwelding.com/Manage\\_Spilled\\_Gas.pdf](http://netwelding.com/Manage_Spilled_Gas.pdf)



### **GS/C7 License Plate & Cargo Lights**

*LED license plate light & cargo area bulbs are brighter and whiter*

[http://netwelding.com/License Plate\\_Light.pdf](http://netwelding.com/License_Plate_Light.pdf)



### **GS/C7 Rear Cargo Area**

*Rear cargo area needs storage device and rear protector*

[http://netwelding.com/Rear\\_Cargo\\_Area.pdf](http://netwelding.com/Rear_Cargo_Area.pdf)



### **C7 Door Panel Protector**

*protector plate added to prevent scuffing of door when exiting*

[http://netwelding.com/Door\\_Panel\\_Protector.pdf](http://netwelding.com/Door_Panel_Protector.pdf)



### **GS/C7 Improved Cup Holder**

*A solution to the cup holder spilling under hard braking or shape turns.*

[http://netwelding.com/Improved\\_cup\\_Holder.pdf](http://netwelding.com/Improved_cup_Holder.pdf)



### **GS/C7 Wheel Chatter/Hop**

*Why sharp, low speed turns with cold tires causes the front tires to chatter/hop.*

[http://netwelding.com/Wheel\\_Chatter.pdf](http://netwelding.com/Wheel_Chatter.pdf)



### **C7 Carbon Fiber Grille Bar**

*Install genuine carbon fiber grille bar overlay*

[http://netwelding.com/CF\\_Grille\\_Bar.pdf](http://netwelding.com/CF_Grille_Bar.pdf)



### **Jacking a GS/C7 Vette**

*Safely jacking either front only or back and front*

[http://netwelding.com/Jacking\\_A\\_C7.pdf](http://netwelding.com/Jacking_A_C7.pdf)



### **Deer Whistle Installed on GS/C7**

*Do they work? Plus Install Info*

[http://netwelding.com/Deer\\_Whistle.pdf](http://netwelding.com/Deer_Whistle.pdf)



### **Replacing C7 Battery**

*After using a GM type charger and showing fully charged, voltage low, replaced battery with AGM!*

[http://netwelding.com/Battery\\_Issues.pdf](http://netwelding.com/Battery_Issues.pdf)



### **GS/C7 Window Valet**

*Lower Windows with FOB*

*Window Valet Helps 2014/2015 Latch Hatch*

[http://netwelding.com/Hatch\\_Latch.pdf](http://netwelding.com/Hatch_Latch.pdf)



### **GS/C7 Splash Guards**

*GM offers splash guards for the C7 Corvette. An easy DIY installation.*

[http://netwelding.com/Splash\\_Guard.pdf](http://netwelding.com/Splash_Guard.pdf)



### **GS/C7 Blind Spot Mirror**

*Smaller rear and side windows cause C7 blind spots. Small "blind spot mirrors" help*

[http://netwelding.com/Blind\\_Spot.pdf](http://netwelding.com/Blind_Spot.pdf)



### **GS/C7 Skid Pad Protector**

*After the air dam, the aluminum "skid pad" hits driveway ramps etc. Plastic protector helps.*

[http://netwelding.com/Skid\\_Pad\\_Protector.pdf](http://netwelding.com/Skid_Pad_Protector.pdf)



### **GS/C7 Wheel Locks**

*Wheel locks, torqued to required 100 ft-lbs, help protect your expensive wheels from theft.*

[http://netwelding.com/Wheel\\_Locks.pdf](http://netwelding.com/Wheel_Locks.pdf)



### **GS/C7 OnStar Lights**

*The OnStar LED's in the rear view mirror, at a quick glance, look like a police car flashing light! This is a fix.*

[http://netwelding.com/OnStar\\_Lights.pdf](http://netwelding.com/OnStar_Lights.pdf)



### **GS/C7 Skip Shift Eliminator**

*Skip Shift Eliminator install with suggestions on jacking a C7.*

[http://netwelding.com/Skip\\_shift\\_Eliminator.pdf](http://netwelding.com/Skip_shift_Eliminator.pdf)



### **C7 Catch Can & Clean Oil Separator**

*Direct inject engines like the LT1, are particularly subject to "coking." What is Coking and how to reduce the potential?*

[http://netwelding.com/Catch\\_Can.pdf](http://netwelding.com/Catch_Can.pdf)



### **GS/C7 Round Shift Knob**

*A round shift knob shortens throw.*

[http://netwelding.com/Shift\\_Knob.pdf](http://netwelding.com/Shift_Knob.pdf)



### **GS/C7 Stingray Sill Plate**

*Stingray sill plate replaces original.*

[http://netwelding.com/Sill\\_Plate.pdf](http://netwelding.com/Sill_Plate.pdf)



### **GS/C7 Nylon Bra**

*Nylon Bra Stops Bugs on Front and Grill.*  
[http://netwelding.com/Nylon\\_Bra.pdf](http://netwelding.com/Nylon_Bra.pdf)



### **GS/C7 Clutch Fluid Change**

*Clutch fluid after 3000 miles gets dirty*  
[http://netwelding.com/Clutch\\_Fluid.pdf](http://netwelding.com/Clutch_Fluid.pdf)



### **C7 Carbon Fiber Hood Vent**

*Replaces Plastic Hood Vent*  
[http://netwelding.com/Hood\\_Vent.pdf](http://netwelding.com/Hood_Vent.pdf)



### **GS/C7 Cold Air Intake**

*Low Restriction Air Filter & Duct*  
[http://netwelding.com/Cold\\_Air\\_Intake.pdf](http://netwelding.com/Cold_Air_Intake.pdf)



### **Garmin GPS for GS Cubby**

*Garmin Mounts in GS Cubby*  
[http://netwelding.com/GPS\\_In\\_Cubby.pdf](http://netwelding.com/GPS_In_Cubby.pdf)



### **GS Splitter Stage 3 Winglet**

*Stage 3 Winglets Intergrate with Spats*  
[http://netwelding.com/Stage\\_3\\_Winglets.pdf](http://netwelding.com/Stage_3_Winglets.pdf)



### **GS 2LT to 2.5 LT**

*Red Upper Dash Pad Like 3LT*  
[http://netwelding.com/Red\\_Dash\\_Pad.pdf](http://netwelding.com/Red_Dash_Pad.pdf)



### **Jake Emblem/Decals for GS**

*Jake Symbols Support GS Racing Image*  
[http://netwelding.com/Jake\\_Emblems.pdf](http://netwelding.com/Jake_Emblems.pdf)



### **GS Splitter Protectors**

*Cone Washers Protect Splitter Bottom*  
[http://netwelding.com/Splitter\\_Protectors.pdf](http://netwelding.com/Splitter_Protectors.pdf)



### **May Be Of Interest: Engineering a ProStreet Rod**

*How Our '34 ProStreet Rod Was Designed and Built  
8.2 Liter Engine, 4 Wheel Disk Brakes & Coilover*  
<http://netwelding.com/Engineering%20Street%20Rod%203-08.pdf>

